

## Care of quartz products

In order to maintain the sink in proper aesthetic and technical condition, one should not allow situations that may cause mechanical, thermal or chemical damage

- Do not use any sharp objects or abrasive materials for cleaning, which may cause scratches or other damage to the Surface
- Do not use aggressive or abrasive agents containing acids, solvents, chlorine and their derivatives
- It is recommended to periodically clean drains and traps with commercially available cleaning agents,
- The surfaces of the sink should be cleaned with clean water and mild cleaning agents that do not scratch the surface, using a soft sponge
- Contact of the sink with any kind of lacquer, nail polish remover, solvents, lit cigarettes, etc. should be strictly avoided
- Strongly coloured substances should be washed off immediately
- The sink should be wiped dry after washing up, which will limit the formation of lime deposits from water on its surface
- Throwing cutlery or other hard, heavy or sharp objects into the sink can sometimes damage the surface -Do not cut or slice food directly on any part of the sink.
- Do not place hot dishes directly on the sink surface -Regularly use non-aggressive limescale remover